



PRODUCT FEATURES

- Comfortable warmth under your table.
- Free movement without the power cable connection in the shoes.
- Leading technology of wireless power transfer.

CONTENTS



USAGE INSTRUCTION

1.



Connect the adapter to the AC plug.

2.



Connect the adapter cable to the contactless power carpet.

3.



Align the rear of the shoes with the mark on the carpet*.

* The shoes will be heated with the alignment.

SPECIFICATION

Input	DC 9V/1A
Radio Frequency	250KHz
AC Adapter	100-240V/50-60MHz

Power Consumption	9W
Working Temperature (Shoes)	32~37°C
LED Indication (Carpet)	Power LED: Light ON/OFF – Power ON/OFF Status LED (Left): Light ON/OFF – Charging/Error Status LED (Right): Light ON/OFF – Charging/Error
Dimension	Electronic Warm Shoes: 273 x 108 x 77(mm)* Contactless Power Carpet: 580 x 390 (mm) AC Adapter: 58 x 31x 51(mm)

*Reference data. Various sizes available.

NOTE

- ※ In the case of shoes cleaning, please use the neutral detergent and brush gently.
- ※ The carpet is not water resistant. Please keep this product away from the liquids and clean it with vacuum cleaner.
- ※ Please keep your hands dry when you set up this product.
- ※ Please pay attention to the adapter and its cable when moving the carpet.
- ※ Please unplug the adapter from the AC plug if this product is not used.
- ※ Please pay attention to the scarce case of scald if you keep using this product in long time.
- ※ We reserve the right for design or specification change for product improvement without notice.

Warranty

Model No.		Warranty <ul style="list-style-type: none"> ● The warranty proves that this product is produced through highly quality control, and provides 1-year warranty since selling data when it is used in normal situation. ● The sheet information should be written down exactly and this warranty will be executive with the signature of the retail shop ● Please do have this warranty in repairing ● Please do well-keep this warranty, We don't give any other warranty when this warranty is lost. ● We free repair product in warrant when it is used in normal situation. ● We will free repair for charge in the following situation when there are any problems: <ol style="list-style-type: none"> 1. There are damages due to external causes, including accident, problems with electrical power, usage not in accordance with product instructions, neglect, alteration, repair, improper installation or improper testing. 2. Do not have this warranty in repairing 3. Do not correctly register data, or data is corrected
Purchaser		
Date of Purchase		
Telephone		
Address		
Retailer		

